

LIMITED WARRANTY

BC Audio warrants this product against defects in materials and workmanship for ONE (1) YEAR from date of original retail purchase (30 days for tubes). BC Audio reserves the right, before having any obligation under this limited warranty, to inspect the damaged product, and all costs of shipping the product to BC Audio for inspection shall be borne solely by the purchaser. In order to recover under this limited warranty, Purchaser must make claim to BC Audio within 30 days of occurrence, and must present acceptable proof of original ownership (such as original receipt) for the product. BC Audio, at its option, shall repair or replace the defective unit covered by this warranty.

This limited warranty does not cover any damage to this product that results from improper installation, accident, abuse, misuse, neglect, natural disaster, insufficient or excessive electrical supply, abnormal mechanical or environmental conditions, or any unauthorized disassembly, repair, or modification. This limited warranty also does not apply to any product on which the original identification information has been altered, obliterated or removed, has not been handled or packaged correctly, has been sold as second-hand or has been resold contrary to the US export regulations.

This limited warranty covers only repair or replacement of defective BC Audio products, as provided above. In the event of a claim, BC Audio's sole obligation shall be replacement of the product.

DISCLAIMER OF WARRANTY

EXCEPT FOR THE LIMITED WARRANTY PROVIDED HEREIN, TO THE EXTENT PERMITTED BY LAW, BC AUDIO DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ALL WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT THAT ANY IMPLIED WARRANTIES MAY NONETHELESS EXIST BY OPERATION OF LAW, ANY SUCH WARRANTIES ARE LIMITED TO THE DURATION OF THIS WARRANTY. SOME STATES/PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

LIMITATION OF LIABILITY

REPAIR OR REPLACEMENT OF THIS PRODUCT, AS PROVIDED HEREIN, IS YOUR EXCLUSIVE REMEDY. BC AUDIO SHALL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO, PROPERTY DAMAGE, LOST REVENUES, LOST PROFITS, RENTAL OF REPLACEMENT EQUIPMENT, DOWNTIME, DAMAGE TO PROPERTY, AND THIRD-PARTY CLAIMS, ARISING OUT OF ANY THEORY OF RECOVERY, INCLUDING WARRANTY, CONTRACT, STATUTORY OR TORT. NOTWITHSTANDING THE TERM OF ANY LIMITED WARRANTY OR ANY WARRANTY IMPLIED BY LAW, OR IN THE EVENT THAT ANY LIMITED WARRANTY FAILS OF ITS ESSENTIAL PURPOSE, IN NO EVENT WILL BC AUDIO'S ENTIRE LIABILITY EXCEED THE PURCHASE PRICE OF THIS PRODUCT. SOME STATES/PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE AND PROVINCE TO PROVINCE.

©2015 Bruce Clement, BC Audio, San Francisco
Other copyrights and trademarks are the property of their respective owners.

www.bcaudio.com

bc audio

hand-made all-tube non-clone guitar amps

Amplifier No. 10 - Mk.II

OWNER'S MANUAL

Models A10-Mk.II



Amplifier No. 10 is a performance-oriented 50 watt Master Volume amp. Its independent Gain Boost and Volume Boost, both variable and footswitch controlled, give you tremendous power at your feet. Construction is heavy-duty, meant for real-world use and abuse. Amplifier No. 10 is made with the highest quality components, USA iron, and true point-to-point wiring.

I sincerely hope you enjoy playing your new Amplifier No. 10 as much as I enjoyed building it.

ESSENTIAL INFORMATION

Tube placement, left to right (facing the rear):

V1	V2	V3	V4	V5	V6
6SL7	6SL7	6SL7	6SL7	EL34	EL34

Your amplifier includes a Line Voltage selector behind the rear panel. The following data is for 120VAC line voltage.


Power: 120VAC, 60Hz, 2A

Mains Fuse: 3A Slow Blow, Type 3AG, 1/4" x 1-1/4"

H.T. Fuse: 500mA, Type 3AG, 1/4" x 1-1/4"

When replacing power tubes, always replace with a matched pair and check and adjust the bias. For detailed information on setting the bias, have your amp technician contact BC Audio.

IMPORTANT SAFETY INSTRUCTIONS



READ, FOLLOW, HEED, AND KEEP ALL INSTRUCTIONS AND WARNINGS. WE MAY COME TO YOUR HOUSE FOR VERIFICATION.

- DO NOT REMOVE SCREWS ON BOTTOM OF UNIT. LETHAL VOLTAGES LURK INSIDE. BOO! CONTACT THE MANUFACTURER FOR SERVICE INFORMATION. SERVICE MUST BE PERFORMED BY QUALIFIED PERSONNEL, NOT YOUR COUSIN WHO WIRED YOUR BASEMENT.
- THIS AMPLIFIER IS CAPABLE OF PRODUCING HIGH SOUND PRESSURE LEVELS. YEAH! CONTINUED EXPOSURE TO HIGH SOUND PRESSURE LEVELS CAN CAUSE PERMANENT HEARING IMPAIRMENT OR LOSS. WHAT? USER CAUTION IS ADVISED AND EAR PROTECTION IS RECOMMENDED IF UNIT IS OPERATED AT HIGH VOLUME, WHICH OF COURSE IT SHOULD BE.
- WHEN POWERED ON, THE TUBES MAY BECOME VERY HOT, HOT ENOUGH TO BURN SKIN ON CONTACT. SO DON'T TOUCH 'EM. AND KEEP OUT OF REACH OF CHILDREN AND PETS.
- DO NOT OPERATE WITHOUT SPEAKER OR OTHER SUITABLE LOAD CONNECTED TO THE SPEAKER JACK, AS DAMAGE TO THE AMPLIFIER AND YOUR REPUTATION MAY RESULT.
- DO NOT OPERATE NEAR ANY HEAT SOURCE, ESPECIALLY A SWEATY ONE.
- DO NOT OPERATE WITH VENTILATION OPENING(S) COVERED, AS THIS MAY OVERHEAT THE AMPLIFIER. DUH.
- DO NOT USE NEAR SPLASHING, FALLING, SPRAYING, OR STANDING LIQUIDS. AND DON'T EVER LET SOME FOOL SET HIS DRINK ON YOUR RIG.
- CLEAN ONLY WITH A LINT-FREE DRY CLOTH. DO NOT USE CLEANING AGENTS. WHO CLEANS THEIR AMP, ANYWAY?
- CONNECT POWER CORD ONLY TO A POLARIZED, SAFETY GROUNDED OUTLET WIRED TO CURRENT ELECTRICAL CODES AND COMPATIBLE WITH VOLTAGE, POWER, AND FREQUENCY REQUIREMENTS STATED ON THE APPLIANCE. THIS MEANS YOU.
- PROTECT THE POWER CORD FROM DAMAGE DUE TO BEING WALKED ON, PINCHED OR STRAINED. IF YOU SMELL AN ELECTRICITY LEAK, CALL THE AUTHORITIES IMMEDIATELY.
- UNPLUG THE APPARATUS DURING LIGHTNING STORMS, WHEN NOT IN USE OR FOR LATE-NIGHT SILENT OPERATION.
- REPLACE FUSE WITH CORRECT TYPE AND RATING AS INDICATED IN THIS MANUAL AND ON THE APPLIANCE. DO NOT STUFF WITH FOIL FROM YOUR CHEWING GUM.
- ONLY USE ATTACHMENTS, ACCESSORIES, STANDS OR BRACKETS SPECIFIED BY THE MANUFACTURER FOR SAFE OPERATION AND TO AVOID INJURY TO YOU AND MEMBERS OF THE AUDIENCE.

FRONT PANEL CONTROLS AND FEATURES, Right to Left

INPUT Standard 1/4" guitar input jack.

GAIN Sets the amount of gain or amplification applied to the signal, and thus the amount of distortion.

GAIN BOOST & Indicator Sets the amount of additional gain when engaged by the included dual foot switch. When engaged, the LED indicators on the front panel and on the foot switch will light. When no foot switch is plugged into the FOOT SWITCH jack, the Gain Boost is engaged.

BASS, MID & TREBLE Tone-shaping controls, placed early in the preamp section, before the gain stages that produce distortion.

VOLUME Functions as a Master Volume control, setting the overall loudness of the amplifier.

VOL BOOST & Indicator Sets the amount of increased volume when engaged by the included dual foot switch. When engaged, the LED indicators on the front panel and on the foot switch will light. When no foot switch is plugged into the FOOT SWITCH jack, the Volume Boost is engaged.

PRESENCE & DEPTH These controls work in the amp's power section to adjust the amp's overall brilliance and low-end thump, respectively. You may hear some scratchiness when rotating PRESENCE and DEPTH. This is normal.

POWER, STANDBY & Indicator When powering up, switch POWER to ON while leaving STANDBY in the OFF position to allow the tubes to warm up. After a half-minute or so, flip STANDBY up to the ON position. To turn the amp off, simply flip both switches down to OFF. There's no need to put the amp in standby mode when shutting down.

REAR PANEL CONTROLS AND FEATURES, Left to Right

FOOT SWITCH Standard 1/4" jack for the included foot switch (depending on installed options).

Effects Loop SEND LEVEL, SEND jack, RETURN jack, RETURN LEVEL and TRUE BYPASS switch are the interface to the powerful fully tube-buffered effects loop. For best performance with guitar pedals, set SEND LEVEL to 5-7 and set RETURN LEVEL to 8-10, being sure to avoid audible distortion in the return circuit. The Send signal is always present, regardless of the position of the TRUE BYPASS switch.

IMPEDANCE Matches the amplifier's output impedance to your speaker cabinet(s).

SPEAKER Two standard 1/4" speaker output jacks. Always use speaker cables - NOT guitar cables - to connect speaker cabinets, or damage to the amplifier may occur. Do not operate the amplifier without a speaker or suitable load connected, as this can cause damage to the amplifier.

Fuses Replace with same type and rating only. The MAINS fuse is on the main power input to the amplifier. The HT or High Tension fuse is on the B+ plate voltage supply.

Mains Input Standard IEC power inlet. Always use a proper grounded power cable. Your amplifier shipped with a Hospital Grade cable for reliability.